

HOW TO BOOK

Call us on

03 9962 8889

Email us at

info@proscan.com.au

or



Scan the
QR code to
book online

HOW TO FIND US

Shop 220, Murnong Street


Stockland Point Cook VIC 3030

PARKING

- Car Park 3, between Rowland Drive and Lawler Street — free, up to 3 hours
- Walk out to Murnong Street and turn right — we face the street
- Accessible parking at every centre entry

PUBLIC TRANSPORT

- Bus 495 — Boardwalk Boulevard
- Bus 498 — Dunnings Road
- Williams Landing Station (1 km), then bus 495



PATIENT PREPARATION PROTOCOLS

ULTRASOUND — PELVIS & RENAL

Preparation

- Take your regular medications
- Empty your bladder 1.5 hours before your appointment
- 1 hour before, drink 1 litre of water within 10 minutes, then do not empty your bladder

Notes

- An internal scan may be recommended for pelvic studies

ULTRASOUND — ABDOMEN

Preparation

- Nothing to eat for 4 hours beforehand
- Keep drinking water
- Take your regular medications

MRI — WITH CONTRAST

Preparation

- Nothing to eat for 2 hours beforehand, or 4 hours before upper abdomen studies
- Take your regular medications

Notes

- Tell us at booking about any clips, coils, stents or implants

MRI — WITHOUT CONTRAST

Preparation

- No preparation required

Notes

- Tell us at booking about any clips, coils, stents or implants

CT — WITH CONTRAST

Preparation

- Nothing to eat for 2 hours beforehand
- Keep drinking water and take your regular medications

Notes

- Tell us about any allergies on the day of your scan
- Warmth, a metallic taste and an urge to pass urine are normal
- Recent blood tests help us assess kidney function

IMAGE-GUIDED PROCEDURES

Preparation

- Take your regular medications

Notes

- Tell us at booking about any blood-thinning medication
- No driving for 4 hours afterwards — please arrange a driver, taxi or rideshare

X-RAY, OPG, CONE BEAM CT & DEXA

Preparation

- No preparation required
- Where possible, wear clothing without metal fastenings